

THE "BLUNDELL" SLIDE RULE

The rule is made of the finest materials obtainable, and every care is taken in its manufacture to ensure that the resulting product is unsurpassed in its durability.

It is fitted with a spring at each end to control the friction between body and slide.

The user can adjust the tension to suit his own requirements by a slight movement of the exposed end of the spring to the right or left, with a pointed instrument. To increase the tension turn clockwise, or vice versa.

To maintain the clarity and ensure the maximum life in the use of the "Blundell" rule, users are advised to observe normal care in its operation; handling of the face with soiled or chemically stained fingers should be avoided.

If it is necessary to clean the surfaces, please do not use abrasives, generally a pure (toilet) soap and water is best.

BLUNDELL RULES LIMITED